



Wall Feed Thru for FLEXWELL® Elliptical Waveguide E58 and E60

Product Description

The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.



Features/Benefits

Elliptical Waveguide installation

- The wall gland provides a single entry in conjunction with a feed through plate
- It consists of a single rubber boot, wall gland and stainless steel clamp

Technical Specifications

Product Line	Elliptical Waveguide Accessories
Product Type	Wall/Roof Feed-Through System
Feed-Through Component	Single Entry Kit
Transmission Line Type	E58, EP58, E60, EP60
Feed-Through Holes	1
Feed-Through Hole Diameter, mm (in)	70 (2.76)
Package Quantity	1

Notes

Other Documentation