

## Wall Feed Thru for FLEXWELL® Elliptical Waveguide E78 and EO15

**Product Description**

The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.

**Features/Benefits****Elliptical Waveguide installation**

- The wall gland provides a single entry in conjunction with a feed through plate
- It consists of a single rubber boot, wall gland and stainless steel clamp

**Technical Specifications**

Product Line	Elliptical Waveguide Accessories
Product Type	Wall/Roof Feed-Through System
Feed-Through Component	Single Entry Kit
Transmission Line Type	E78, EP78, EO15
Feed-Through Holes	1
Feed-Through Hole Diameter, mm (in)	55 (2.17)
Package Quantity	1

**Notes****Other Documentation**

Installation Instruction: [2800063-b.pdf](#)