



Wall Feed Thru for FLEXWELL® Elliptical Waveguide E185

The kit consists of wall gland, a single rubber boot and tension clamp with two bolts.

FEATURES / BENEFITS

Elliptical Waveguide installation

- ➔ The wall gland provides a single entry in conjunction with a feed through plate
- ➔ It consists of a single rubber boot, wall gland and stainless steel clamp



Technical Features

STRUCTURE

Product Line		Elliptical Waveguide Accessories
Product Type		Wall/Roof Feed-Through System
Feed-Through Component		Single Entry Kit
Transmission Line Type		E185, EP185

MECHANICAL SPECIFICATIONS

Feed-Through Holes		1
Feed-Through Hole Diameter	mm (in)	40 (1.58)

PACKAGING INFORMATION

Package Quantity		1
------------------	--	---

External Document Links

Notes

Installation Instruction